



TREMproof FBM Butt Adhesive Tape

HDPE Pressure Sensitive Adhesive Tape

DESCRIPTION

TREMproof FBM Butt Adhesive Tape is constructed using high-density polyethylene (HDPE) membrane, bolstered by a specialized hot melt pressure-sensitive adhesive, and furnished with a release liner. Its exceptional adhesive qualities enable robust and long-lasting connections for sheet butt joints, ensuring durability and reliability.



BASIC USES

- TREMproof FBM Butt Adhesive Tape is a 160mm-wide tape used in detail areas including butt joints, selvedge overlaps and various tie-ins.

INSTALLATION

- Clean the base material to ensure the surface of the bonded base material is free of dirt by wiping the surface with a rag.
- Cut off the butt adhesive tape, back the short edge alignment part of two sheets of sheets with the adhesive tape, and tear off the release liner at both side respectively.
- Use a lap roller to remove the air, and bond tightly.

PACKAGING

- Roll Size: 160mm x 20m
- Tape Thickness: 1.2mm

WARRANTY

Tremco warrants its Products to be free of defects in materials but makes no warranty as to appearance or colour. Since methods of application and on-site conditions are beyond our control and can affect performance. Tremco makes no other warranty, expressed or implied, including warranties of MERCHANTABILITY and FITNESS FOR A PARTICULAR PURPOSE, with respect to Tremco Membranes. Tremco's sole obligation shall be, at its option, to replace, or refund the purchase of the quantity or Tremco Membranes proved to be defective and Tremco shall not be liable for any loss or damage.

To find your local office address and contact details, visit

www.tremcocpg-asiapacific.com

REV21/06/24