SPEED PLUG

RAPID-SETTING HYDRAULIC CEMENT

DESCRIPTION

SPEED PLUG is a rapid-setting hydraulic cement compound used to instantly stop running water or seepage in masonry or concrete. **SPEED PLUG** is ready to use and requires only the addition of water before plugging and sealing active leaks.

PRIMARY APPLICATIONS

- Concrete & masonry walls and floors
- Dams, swimming pools, cisterns, reservoirs, water tanks and manhole repairs

Features / Benefits

- Non-shrinking, non-metallic and noncorrosive
- Initial set in 1 to 3 minutes
- Stops running water or seepage leaks

TECHNICAL INFORMATION

Material Properties at 24°C

Compressive Strength ASTM C 109 MPa	
1 hour	10.0
1 day	17.0
28 days	50.0
Flexural Strength ASTM C 348	
7 days	2.5
28 days	3.2

High strength

- Controlled expansion
- Can be applied underwater

Appearance

SPEED PLUG is a grey hydraulic cement compound

WATERPROOFING

Values presented are typical and not necessarily referenced to create specifications.

Packaging

SPEED PLUG is packaged in 5 kg plastic pails.

SHELF LIFE

1 year in original, unopened package

Coverage

5 kg of SPEED PLUG yields approximately 0.0025m³.

DIRECTIONS FOR USE

Surface Preparation: Concrete surfaces must be structurally sound, free of loose or deteriorated concrete and free of dust, dirt, paint, efflorescence, oil and all other contaminants. Properly clean profiled area.

Priming: Clean and prime exposed steel with suitable reinforcement protective coating and allow to fully dry prior to the application of **SPEED PLUG**.

www.tremcocpg-asiapacific.com



Mixing: Pour potable water into a clean mixing container and gradually add **SPEED PLUG**. Use approximately 1.2 - 1.5 kg of water for 5 kg of materials. Mix rapidly with a trowel to the consistency of stiff putty with no slump for no more than 30 seconds. **SPEED PLUG** will flash set in 60 to 90 seconds. Properly mixed, **SPEED PLUG** can be hand formed into a ball.

Application: SSD areas for repair with potable water immediately before application of SPEED PLUG.

General Patching: Force **SPEED PLUG** into the crack or hole by hand or with a trowel. Rapidly fill to the full depth of the opening.

Patching Active Leaks: Start at the top of the crack or hole, and force the **SPEED PLUG** to the full depth of the prepared area. Apply direct pressure to the new patch until the **SPEED PLUG** has taken a firm set. Mix fresh material, and continue patching toward the area of the greatest pressure. When extreme water pressure is encountered, physically hold the mixed **SPEED PLUG** with a hand against the leak and apply continuous pressure until the **SPEED PLUG** has set, and the water has stopped running. Do not use a twisting motion.

Floor-Wall Patching: Follow above methods for the specific conditions encountered. Use a rounded tool to force the **SPEED PLUG** into the joint, and construct a 45° transitional cove between the floor and wall at the same time.

Expansion/Contraction Cracks: Do not use SPEED PLUG to treat dynamic cracks.

CLEAN UP

Clean tools and mixing equipment with water immediately after use.

PRECAUTIONS / LIMITATIONS

- Do not retemper SPEED PLUG. Do not apply SPEED PLUG to frozen or frost filled surfaces.
- Do not twist **SPEED PLUG** into the hole while plugging running water leaks.
- Do not prewet in cold weather.
- Do not use in dynamic (moving) cracks or expansion joints.
- In all cases, consult the Safety Data Sheet before use

Rev: 30/06/20

DISCLAIMER: Tremco CPG Malaysia's products are guaranteed against defective materials and manufacture and are sold subject to its standard Terms and Conditions of Sale, copies of which can be obtained on request. Any suggested practices or installation specifications for the composite system (as opposed to individual product performance specifications) included in this communication (or any other) from Tremco CPG Malaysia Sdn Bhd constitute potential options only and do not constitute nor replace professional advice in such regard. Tremco CPG Malaysia Sdn Bhd recommends any customer seek independent advice from a qualified consultant prior to reaching any decision on design, installation or otherwise.